

TECHNICAL DATA SHEET

Chemotherapy Prep Mat - Sterile



DESCRIPTION

Incorporating a proven 3 ply blue-mesh structure, the Berner Cytotoxic Work mat is designed for effective absorption and containment of accidental cytotoxic drips and spills. A lint-free polypropylene top layer provides effective product protection during preparation activities, with an absorbent middle layer to contain and distribute spilled agents without losing shape. A non-slip bottom layer provides additional stability and prevents any spilled liquids from seeping onto the surface.



TECHNICAL SPECIFICATION

Material	Polypropylene
Quantity	Case of 50 mats
Dimensions	Each mat: 260mm x 420mm (10.2" x 16.5")
Irradiation standard	Gamma 25kGy
Sterility	Sterile using ETO (Ethylene Oxide method)

FEATURES

- Proven 3 layer protective system
- Extra absorbent
- Non-slip backing
- Reliable cytotoxic barrier properties
- Lint free and sterile
- Suitable for use in latex-free areas, and up to ISO 4 (Class A) environments