



## INSTRUCTIONS FOR USE VISITOR COAT FOR MINIMAL RISK ONLY

The manufacturer does not take any responsibilities for damages due to improper use of the garment or any use that does not comply with the following instructions.

It is the responsibility of the user to ensure that a risk assessment is carried out to determine the suitability of the protective garment for the application and environment to be used in.

### DESCRIPTION OF PRODUCT: Visitor Coat for Minimal Risk Only

Multi Purpose Visitor Coat to provide minimum protection, with collar, zip closing, elasticated wrists. Internal breast pocket.

**Colour:** White

**USE:** Clothing to be worn to protect against non dangerous dust and dirt. This garment is not liquid or chemical resistant.

Manufactured from polypropylene

Certified to category I EU Directive 89/686

Store in a cool, dry place.

Keep out of Direct Sunlight

Packaging : 1 garment per bag, 50 garments per case

Do not wear near heat sources or flame.

Dispose of worn garment and packaging responsibly

### AVAILABLE SIZES:

SIZE	CHEST GIRTH (cm)	HEIGHT* (cm)
S	112	98
M	128	100
L	132	102
XL	144	104
XXL	168	108

\*Length of garment measured from the shoulder to the knee

**WAY OF DRESSING:** Open the zipper, insert arms, and dress taking care not to break the material. Close the zipper.

**NB:** The protection characteristics are valid only if the item is correctly dressed. Cleanroom Supplies Limited does not take any responsibility for any improper use of the garment.

**MAINTENANCE AND CLEANING:** disposable item, single use - barred symbols

DON'T wash	DON'T iron	DON'T tumble dry	Inflammable. Keep Away From Flame

**CONSERVATION AND DISCARDING:** The item should be conserved in a dry place away from sources of light and heat. If not contaminated the product can be treated as a normal use item. If contaminated it should be treated as harmful garbage and discarded according to country laws.

**EXPIRATION:** It is suggested to use the product within a period of five years from the date of purchase.

**WARNINGS:** make sure that the size corresponds with the end user. Do not make any modifications to the product.

- **Check that the product has no defect and is in good condition (no holes, unsewn parts, etc.)**
- **Abandon the place of work immediately in case of damage to the product**
- **These garments are flammable - Keep away from fire**
- **Do not re-use once worn**

Protect uncovered body parts (hands, feet, respiratory areas) with additional suitable protective equipment.