

PRODUCT DATA SHEET

INDUSTRIAL SURFACE WIPES

Benefits

- Available in handy 100 and 300 wipe tubs
- Removes finger marks, dirt, grime, oil, grease, petrol inks, food stains, part cured sealant and paint smears
- Resistant to MRSA, Salmonella, Listeria and E.coli
- Easily remove oil, grease, petrol and inks
- Powerful cleaning agents are still kind to hands



Product Description

- Specially formulated for the building and allied trades to clean wet and semi-cured paints, sealants, adhesives, bitumen's
- Polyurethanes, expanding foams, Polyester fillers and Epoxies from hands, tools and surfaces
- Contains a powerful antibacterial additive which has been tested by an independent laboratory to BSEN 1276:2009 and PREN 12054:1995, the standards for killing bacteria on dirty surfaces and hands

Instructions for Use

- 100 or 300 wipe size: Pull off black lid and open closure. Find start wipe in centre of roll. Pull out approximately 1 foot of wipes and thread through black lid. Replace black lid immediately and reseal closure
- Wipe on hand/spills, use immediately for best results

Health & Safety

- Consult MSDS for full list of hazards

Storage

- Store in cool dry conditions away from direct sunlight between 5 and 25°C. Storage outside these parameters will significantly reduce shelf life
- Ensure good ventilation

Shelf Life

- 36 months from date of manufacture

Limitations

- Do not use on porous surfaces such as untreated wood
- Do not dispose of wipes in toilets
- Use only as directed
- Store only in original container
- As with all detergents, people with sensitive or damaged skin should avoid prolonged contact with skin
- It is the users responsibility to determine suitability for use. If in doubt contact technical services department for advice