

# TECHNICAL DATA SHEET

## Cleanroom Trolley Transfer Hatch



### DESCRIPTION

Cleanroom Supplies transfer hatches (also know as pass through or pass thru hatches) are designed and manufactured with our knowledge and experience in cleanroom design and construction. This means we are up to date with current standards and regulatory requirements. Transfer hatches are provided in a cleanroom environment in order to reduce contamination between areas whilst passing product or consumables without loss of differential pressure. By interlocking the 2 opposing doors so that only one door can be open at any time, room differential pressures are maintained.



### TECHNICAL SPECIFICATION

Materials Available	304 Grade Stainless Steel 316 Grade Stainless Steel TRESPA (a solid grade laminate) Polypropylene
Lead Time	Approximately 4-5 weeks from approval

### FEATURES

- Flush Welds
- Easy clean surfaces
- Wide range of customisation options
- Bespoke product

### CUSTOMISATION OPTIONS:

- Laminated or Toughened Glass
- Mechanical or Electronical Interlock
- Passive or Active Air Purge
- HEPA Filtration
- Shelving
- Internal Lighting and Power
- Electropolished Finish (Stainless Steel options only)
- UV Disinfection Lighting
- Fire Rating