

TECHNICAL DATA SHEET

Moldex Easylock Filter System



DESCRIPTION

Easy handling as no adapters or particulate filter holders are required. The pre-assembled filter combinations offer the simplicity of combined filters and are more economical at the same time due to exchangeable pre-filters. All products and packaging are 100% PVC free.



TECHNICAL SPECIFICATION

Material	Polypropylene, polystyrene
Test Standard	EN 14387:2004 + A1:2008 EN 143:2000 + A1:2006
Protection Level	P3
Workplace Exposure Limit (WEL)	20x
Quantity	Single pair or 6 pairs

FEATURES

- Bayonet Connector
- Reduces breathing resistance
- Increases the capacity of the particulate filters
- Easylock System
- Adaptors and Particulate
- 100% PVC free
- Pre assembled
- CE certified
- Easy handling
- 100% PVC free

TECHNICAL DATA SHEET

Moldex Easylock Filter System



Instructions for use:

- The mask and the filters must be selected in accordance with the pollutant concentration.
- In the case of gasses with insufficient warning properties, filters may only be used if special usage policies are specified for this purpose.
- If the conditions are uncertain or changeable, a self-contained breathing apparatus must be worn.
- The product does not contain any metallic parts that could cause ignition in potentially explosive atmospheres.

Certification:

- The easylock filters meet the requirement of EN 14387:2004+ A1:2008 and EN 143:2000 + A1:2006 and are CE marked in accordance with the requirements of European Directive 89/686 EEC
- The products are manufactured in an ISO 9001 certified plant.

