

TECHNICAL DATA SHEET



Trespa Cleanroom Wall Transfer Hatch

DESCRIPTION

Cleanroom Supplies transfer hatches (also know as pass through or pass thru hatches) are designed and manufactured with our knowledge and experience in cleanroom design and construction. This means we are up to date with current standards and regulatory requirements. Transfer hatches are provided in a cleanroom environment in order to reduce contamination between areas whilst passing product or consumables without loss of differential pressure. By interlocking the 2 opposing doors so that only one door can be open at any time, room differential pressures are maintained and cross contamination minimised.



TECHNICAL SPECIFICATION

| | |
|-----------|---------------------------------------|
| Material | Solid Grade Trespa® Laminate |
| Lead Time | Approximately 4-5 weeks from approval |

FEATURES

- Laminated or Toughened Glass
- TRESPA Standard colour is white with black core
- Easy Clean Surfaces
- Mechanical or Electronic Door Interlocks
- Passive or Active Air purge or HEPA filtration
- Internal lighting or power
- Shelving
- UV Disinfection Lighting