

TECHNICAL DATA SHEET

Wall Mounted Hand Automatic Dispenser



DESCRIPTION

A wall-mounted, automatic dispenser for use with any hand sanitising gel. Manufactured from robust ABS plastic, it contains a 1.2L reusable reservoir, allowing you to easily refill the dispenser with sanitiser once it's empty. Suitable for use with most hand sanitisers on the market. Touch-free dispensing brings better hygiene to any environment and helps monitor usage by controlling the amount dispensed. No electrical fitting is required, as each dispenser is economically operated by size C batteries. To ensure optimum cost savings, the device has a "sleep" mode and a capacitive sensor that prevents accidental dispensing. This version comes with a liquid pump for hand sanitising gels.



TECHNICAL SPECIFICATION

Material	ABS Plastic
Volume	1.2L
Dimensions	265mm (H) x 169mm (W) x 102mm (D)
Batteries	Takes 4 x size C (not included)

FEATURES

- Suitable for most hand sanitisers
- Robust ABS Plastic
- Large window for checking sanitiser levels
- Battery powered, touch-free dispensing
- Hygienic