



INSTRUCTIONS FOR USE OVERSLEEVES FOR SPLASH RESISTANCE

The manufacturer does not take any responsibilities for damages due to improper use of the garment or any use that does not comply with the following instructions.

It is the responsibility of the user to ensure that a risk assessment is carried out to determine the suitability of the protective garment for the application and environment to be used in.

DESCRIPTION OF PRODUCT: Oversleeves for protection Against Splash
Individual sleeve covers with option for elasticated wrist or knitted wrist cuff.

Colour: White

USE: Clothing to be worn to protect against light spray, liquid aerosol or low pressure/low volume splashes, airborne solid particulates.

AVAILABLE SIZES:

One Size Suits All

Suitable for:

- Protection against particular-tight (type 5)
- Protection against chemical splash (type 6)
- ANTISTATIC PROPERTIES

ANTI-STATIC PROPERTIES: The product is made following EN1149-5 dissipate electro-static energy standards.

- Person wearing the electrostatic dissipative protective clothing shall be properly earthed. The resistance between the person and the earth shall be less than $10^8\Omega$ e.g. by wearing adequate footwear;
- Electrostatic dissipative protective clothing shall not be opened or removed whilst in the presence of flammable or explosive atmospheres or while handling flammable or explosive substances;
- Electrostatic dissipative protective clothing shall not be used in oxygen enriched atmospheres without prior approval of the responsible safety engineer;
- The electrostatic dissipative performance of the electrostatic dissipative protective clothing can be affected by wear and tear, laundering and possible contamination;

electrostatic dissipative protective clothing shall permanently cover all non-complying materials during normal use (including bending and movements).

NB: The protection characteristics are valid only if the item is correctly dressed. Cleanroom Supplies Limited does not take any responsibility for any improper use of the garment.

MAINTENANCE AND CLEANING: disposable item, single use - barred symbols

DON'T wash	DON'T iron	DON'T tumble dry	Inflammable. Keep Away From Flame

CONSERVATION AND DISCARDING: The item should be conserved in a dry place away from sources of light and heat. If not contaminated the product can be treated as a normal use item. If contaminated it should be treated as harmful garbage and discarded according to country laws.

EXPIRATION: It is suggested to use the product within a period of five years from the date of purchase.

WARNINGS: make sure that the size corresponds with the end user. Do not make any modifications to the product.

- **Check that the product has no defect and is in good condition (no holes, unsewn parts, etc.)**
- **Abandon the place of work immediately in case of damage to the product**
- **These garments are flammable - Keep away from fire**
- **Do not re-use once worn**

Protect uncovered body parts (hands, feet, respiratory areas) with relevant protective equipment.

Choose products compatible with area of work.